


Connected devices

In the left bottom corner of the intro screen you can see if your trainer is correctly connected to the computer. In case of a correct connection the pictograms are reproduced under connected devices with data regarding serial number, version and the software's production date behind them.



Bushido handlebar computer with wireless brake



i-Magic interface with electric brake



VR interface with engine brake




Vortex handlebar computer with wireless brake

No connection

If there is no connection the different pictograms will be displayed in black and white. Check to see if the USB cable has been correctly inserted and that the adaptor switch is on. Another cause may be incorrect installation of the driver. Read the FAQ on Tacx' web site in case of problems with USB connection and driver installation.

When there is a correct USB connection between PC and the VR interface, the yellow LED will be on. A correct connection with the brake is indicated by a green LED (blinking)



No connection


Connecting Bushido / Vortex

The Bushido and Vortex ergotrainers may be **linked** directly to your PC under connected devices.

- More info: [The function buttons > Bushido / Vortex](#)

Online up-date

There are regular up-dates available for the Tacx Trainer software and trainers. We recommend you always use the latest version of the software. When your PC is connected to the internet and an up-date for the Tacx Trainer software, the handlebar mounted computer or brake is available, the **Download** button will appear on the intro screen and you should follow the instructions the installation program gives you.



If the computer is not connected to the internet you have the possibility to download the up-date by means of another computer, from the web site www.tacx.com > service > software up-dates and manual installation. You will also find the instructions regarding the different up-dates on the web site.